

Camel Climb Junior - Single Hump - Freestanding • Model TFR16985XX

INSTALLATION GUIDELINE

USER GROUP: 2-5 Years

RECOMMENDED CREW: 2 People

TOOLS REQUIRED:

- TT-45 Torx
- Level, Square
- Auger / Post Hole Digger / Shovel
- Drill Bits: 21/64"
- High Speed 3/8" Electric Drill with Clutch

NOTE: Use of any other driver may result in damage to tool and/or hardware!


INSTALLATION TIME: 1 Hour

WEIGHT: 68 lbs.

CONCRETE REQUIRED: (12) 80lb. bags

NOTE: Concrete must have a minimum rating of 2,500 psi and must be mixed per manufacturer's recommendations.

ITEM	Part No.	QTY	DESCRIPTION
1	AFB47966XX	1	Wldmt. - Camel Back Top Hump
2	FAB316989XX	4	Single Hump Jr. End Post
3	HWS0081	4	3/8" x 1-1/4" Self Tapping Torx w/patch



PRE-INSTALLATION CHECK:


Customer is responsible for verifying materials received by comparing received items with packing list. If any parts are missing or damaged, contact your local sales representative immediately.

Supplier is not responsible for items discovered missing after 72 hours from time of delivery.

Before beginning installation, all installers must read and understand the Installation Introduction manual as supplied. If you did not receive a copy, or if you have any questions regarding any information in the Installation Instructions or this Installation Guideline, contact your local sales representative.

STEP 1



Prepare footing holes. Refer to site plan drawing and site elevation drawing for placement of all support posts. Installer is responsible for proper location of all support posts. Footing hole spacing is shown below. Footing holes for support posts must be 18" diameter and 24" deep plus surfacing. Place one block (not included) into bottom of each footing hole. **DO NOT ADD CONCRETE.** Footing holes will be completed at STEP 3. Proceed to STEP 2.



STEP 2

Connect end posts to top hump. Insert end posts into top hump. Ensure posts fit flush. At each post, drill one (1) $21/64$ " pilot hole through pre-drilled hole in top hump and into end post. Secure with one (1) $3/8$ " x $1-1/4$ " self-tapping security Torx. See Detail 2-1. Repeat for all end posts.

Detail 2-1



STEP 3

Complete setting of footing holes. Ensure support posts are plumb. Ensure blocks are beneath all support posts. Fill footing holes with concrete to within 3" from ground surface. Allow concrete to cure based upon manufacturer's instructions. Backfill footing holes with dirt, flush with grade. See Detail 3-1 for footing hole details.

Check all connections and ensure structure is stable. All concrete must be fully cured before use of structure. Installation is complete.

Place one (1) Age Appropriate Sticker on structure in a clearly visible location.

Detail 3-1

